

# How to use tear off appliqué fabrics

1.

Use a sharp point needle size 60 - 70 **MXK5S** to pierce through the fabric and create a cleaner appearance.

2.

**Digitising for Vellutex, Pelltex and Glitter Lux** - create the design using two outer edge stitched borders placed 1 - 2mm apart. The internal border can either be a running or decorative pattern stitch i.e. feather stitch and must be 1.5mm wide. The outer edge must be a Satin/Steil border with a zig zag underlay. Increase stitch density slightly from 0.4mm to 0.35mm.

3.

**Digitising for Rasotex and Texcotton badges** - create the design using a double zig zag underlay with a running stitched outer edge which must be 2mm from the edge of the satin stitched border. Increase stitch density for your satin border from 0.4mm to 0.3mm.

4.

**How to apply Vellutex, Pelltex and Glitter Lux** - Cut the fabric slightly larger than the stitched design, hoop up the garment securing the appliqué fabric with either sticky tape or temporary adhesive spray, **MSA 1100** or **AD505**. Once stitched, remove from the hoop, make an initial cut and carefully pull away the excess fabric.

5.

**How to apply Rasotex and Texcotton** - hoop up the fabric and place in the machine, no need for backing fabric. Stitch the design then remove from the hoop. To easily remove, cut up to the edge of the satin stitch border and carefully cut around the contour of the badge.

6.

Your badge can be applied either by sewing directly onto the garment or bond using Heatseal Film **035HP855**. When using Heatseal Film take care to follow the heat setting recommendations for the Rasotex and Texcotton.

7.

**NB.** Store in a dry place between 5 - 25°C.  
It is advisable to wash appliqué fabrics inside out.

## Learn More:

Punch Book - Digitising for Embroidery design by Bonnie Nielsen

One day training course information contact: [sales@madeira.co.uk](mailto:sales@madeira.co.uk)

2019

# MADEIRA